



**A-35244 ACCELERATOR ROD
FLOORBOARD WASHER SEAL**
Remove accelerator cap and
position floorboards. Push
washer over rod, move up &
down to find best location.
Tack down using (3) tacks at
location "A" or (4) tacks at
location "B". Both patterns
were originally used.